RH16CFrequency Programming

Content provided is included for the sole purpose of providing educational information on a passive basis. Frequencies shown have been compiled from various sources. It is the end user's repsonsibility to observe FCC regulations for proper use and programming of any radio frequency.

updated December 21, 2016

- Your RH16C comes with 5 "banks" which hold 16 channels each.
- You must be in the correct bank to select the desired channel/frequency.
 - 1) With the radio turned off, turn the top knob to represent the desired bank i.e. 1,2,3,4, or 5.
 - 2) Press and hold the middle button on the side of the radio (below PTT) as you turn it on.
 - 3) Continue to hold the button until the radio beeps twice (approxiamtely 7 seconds)
 - 4) The radio will announce the channel number it's on.

BANK 1 VHF

DAIR I VIII				
Channel	Name	Frequency	Tone	
1	WTHRMN	151.625		
2	BFGRLY	151.715		
3	BAJAPTS	154.980		
4	NETWORK	151.685		
5	CHECKRS	151.925		
6	FAIR	150.860		
7	YOKOHAM	153.110		
8	RGDRLY	152.960		
9	CHKRS 2	151.505		
10	BFGPITS	153.395		
11	MAG 7	153.380		
12	RESCUE	155.160		
13	CORE	153.245		
14	PRIVATE	156.675	DCS 023N	
15	SANDLMO	152.510		
16	PCI RLY	154.515		

BANK 2 UHF

Channel	Frequency	Tone	
17	464.5000	67.0	
18	464.5500	79.7	
19	467.7625	D023N	
20	467.8125	D023N	
21	467.8500	D023N	
22	467.8750	D023N	
23	467.9000	D023N	
24	467.9250	D023N	
25	462.5750	D023N	
26	462.6250	D023N	
27	462.6750	D023N	
28	464.3250	D023N	
29	464.8250	D023N	
30	469.2625	D023N	
31	469.5000	D023N	
32	469.5500	D023N	

BANK 3 UHF

Channel	Name	Frequency	Tone
33	GMRS 1	462.5625	
34	GMRS 2	462.5875	
35	GMRS 3	462.6125	
36	GMRS 4	462.6375	
37	GMRS 5	462.6625	
38	GMRS 6	462.6875	
39	GMRS 7	462.7125	
40	GMRS 8	462.550	
41	GMRS 9	462.575	
42	GMRS 10	462.600	
43	GMRS 11	462.625	
44	GMRS 12	462.650	
45	GMRS 13	462.675	
46	GMRS 14	462.700	
47	GMRS 15	462.725	
48	GMRS 16	462.750	

BANK 4 VHF

<u>Channel</u>	Name	Frequency	<u>Tone</u>
49	WX 1	162.550	
50	WX 2	162.400	
51	WX 3	162.475	
52	WX 4	162.425	
53	WX 5	162.450	
54	WX 6	162.500	
55	WX 7	162.525	

BANK 5 VHF

<u>Channel</u>	Name	Frequency	Tone
65	BITD	151.490	
66	KOH 1	157.450	